




**INSTRUCTION MANUAL**  
**MANUAL DE INSTRUCCIONES**  
**MANUAL D'INSTRUCTIONS**



## THE XBOX VIDEO GAME SYSTEM



You can play Xbox games and audio CDs with the Xbox™ video game system from Microsoft. Make sure you have received all of the following components of the Xbox video game system in this package:

- Xbox console
- Xbox Controller S
- Xbox Standard AV Cable
- Power cord
- Instruction Manual and other printed materials

### Please keep these instructions.

If you have questions about this product, see [www.xbox.com](http://www.xbox.com) or call

**United States and Canada:**  
**1-800-4MY-XBOX (1-800-469-9269)**  
**Mexico: 001 866 745 83 12**

**TTY users (requires special equipment for hard of hearing):**

**United States and Canada:**  
**1-866-740-9269 or 1-425-635-7102**  
**Mexico: 001 866 251 26 21**

## XBOX PERIPHERALS

The following Xbox peripherals are sold separately:

- Xbox Controller S – gamepad
- Xbox Controller – gamepad
- Xbox Memory Unit – portable storage expansion device
- Xbox System Link Cable – cable to connect two Xbox consoles for head-to-head multiplayer games
- Xbox DVD Movie Playback Kit – remote control and receiver for playing DVD movies
- Xbox Standard AV Cable – composite AV adapter
- Xbox Advanced AV Pack – S-video and digital audio adapter
- Xbox High Definition AV Pack – component video and digital audio adapter
- Xbox RF Adapter – antenna (coaxial cable) adapter
- Xbox Communicator – voice and command headset expansion device

### For customers in the USA:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*Note* Any changes or modifications made on the system not expressly approved by the manufacturer could void the user's authority to operate the equipment.

## TABLE OF CONTENTS

The Xbox Video Game System.....	ii
Xbox Peripherals.....	ii
Table of Contents .....	1
Important Safety Information .....	2
Important Health Warnings .....	4
Selecting a Location for the Xbox Console .....	5
Connecting to a TV.....	6
Connecting Xbox Controllers .....	7
Using Xbox Controllers.....	7
Turning on the Xbox Console .....	8
Initial Setup.....	9
Audio, Video and Other Settings .....	9
Playing Games and Music .....	10
Soundtracks .....	11
Parental Control.....	11
Managing Memory .....	12
Multiplayer Games .....	12
Xbox Live™ .....	13
Connecting Hardware.....	13
Updating the Xbox Dashboard.....	14
Xbox Live Sign Up .....	14
Cleaning the Xbox Video Game System.....	14
Troubleshooting.....	15
Specifications.....	16
Warranty .....	17
ESRB Ratings Guide.....	19
Copyright.....	62

Declaration of Conformity

Trade Name: Microsoft Corp.

Responsible Party: Microsoft Corporation

Address: Xbox Customer Care  
One Microsoft Way  
Redmond, WA, 98052 U.S.A.

Telephone No.: 1-800-4MY-XBOX (1-800-469-9269)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

**For Customers in Canada:**  
This Class B digital apparatus complies with Canadian ICES-003.

The following symbols are used on labels on the Xbox video game system from Microsoft:

- This symbol is intended to alert the user to the presence of important safety, operating, and maintenance instructions in the literature accompanying the console.
- This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

**Warning: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.**



## IMPORTANT SAFETY INFORMATION

This manual contains important information about how to safely and properly set up, use, and care for the Xbox video game system.



### WARNING

Failure to properly set up, use, and care for the Xbox video game system can increase the risk of electric shock or fire. It can also increase the risk of the Xbox console falling and possibly hitting someone. To reduce the risk of serious injury or death, or damage to the Xbox video game system:

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.

### Stay Away from Dangerous Voltage Inside the Xbox Console



Dangerous voltage is present inside the Xbox console whenever it is connected to power, whether it is turned on or off. Contact with dangerous voltage can cause serious injury or death from electric shock. It can also lead to fire or damage to the Xbox console. To eliminate all voltage to the Xbox console, you must unplug the power cord from the power outlet. To reduce the risk of electric shock, fire or damage to the Xbox console:

### Do not take the Xbox console apart.

Do not attempt to service or repair the Xbox console yourself. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as:

- Power-supply cord or plug is damaged.
- Liquid has been spilled or objects have fallen into the apparatus.
- The apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not attempt to modify the Xbox console in any way.

### Do not push or insert anything into ventilation openings.

- Take precautions to keep children from putting anything, especially metal objects, inside the Xbox console.
- Do not insert objects into ventilation openings when cleaning the Xbox console.
- Be alert for sounds of a loose object inside the Xbox console. If you ever notice or suspect there is a loose object inside the Xbox console:
  - Immediately unplug the Xbox console from the power outlet and do not use the Xbox console.
  - Call the Microsoft Xbox Customer Support number on page ii.
- Do not touch the metal parts of any cord coming out of the Xbox console when the console is plugged in to power.
- Always unplug the Xbox console from the power outlet before connecting or disconnecting the Xbox console to/from a TV, VCR, or other AV device.

### Take Precautions to Keep the Xbox Console from Falling

If the Xbox console falls and hits someone, especially a small child, it could cause serious injury. To reduce the risk of such injuries or damage to the Xbox console, properly set up and use the Xbox video game system according to the instructions in **Selecting a Location for the Xbox Console** on page 5 and in **Inline Release** on page 7.

**IMPORTANT SAFETY INFORMATION****General Electrical Precautions**

As with many other electrical devices, failure to take the following precautions can result in serious injury or death from electric shock or fire, or damage to the Xbox video game system.

**Avoid damaging the power cord.**

- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Do not jerk, knot, sharply bend, or otherwise abuse the power cord.
- Do not expose the power cord to sources of heat.
- Keep children and pets away from the power cord and do not allow them to bite or chew on it.
- When unplugging the power cord from the Xbox console or a power outlet, pull on the plug—do not pull on the cord.

If the power cord becomes damaged in any way, stop using it immediately and call the Microsoft Xbox Customer Support number on page ii.

**Do not overload an extension cord, wall outlet, or other type of receptacle.**

The Xbox video game system can consume up to 100 watts. Do not exceed the stated ratings of cords or receptacles.

**Use the type of power source indicated on the Xbox console.**

If you are not sure of the type of power supply to your home, consult a qualified electrician.

**Do not expose the Xbox video game system to liquids or moisture.**

- Do not use this apparatus near water (for example, sinks, tubs, pools) or expose it to rain, moisture, or dripping or splashing liquids.
- Do not place objects filled with liquids, such as beverages or vases, on or near the Xbox console.
- Do not clean the Xbox console with water, liquid cleaners, solvents, or aerosols.

**Clean the outside of the Xbox console properly.**

Clean only with a dry cloth. For more information, see **Cleaning the Xbox Video Game System** on page 14.

**Unplug this apparatus during lightning storms or when unused for long periods of time.**

Also, do not leave the Xbox video game system unattended with the power on for extended periods.

**Only use attachments/peripherals specified by the manufacturer.****Prevent the Xbox Console from Overheating**

**Do not block any ventilation openings.** Install in accordance with the manufacturer's instructions. For more information, see **Selecting a Location for the Xbox Console** on page 5.

**Do not install near any heat sources,** such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

## IMPORTANT HEALTH WARNINGS

### About Photosensitive Seizures

A very small percentage of people may experience a seizure when exposed to certain visual images, including flashing lights or patterns that may appear in video games. Even people who have no history of seizures or epilepsy may have an undiagnosed condition that can cause these "photosensitive epileptic seizures" while watching video games.

These seizures may have a variety of symptoms, including lightheadedness, altered vision, eye or face twitching, jerking or shaking of arms or legs, disorientation, confusion, or momentary loss of awareness. Seizures may also cause loss of consciousness or convulsions that can lead to injury from falling down or striking nearby objects.

**Immediately stop playing and consult a doctor** if you experience any of these symptoms. Parents should watch for or ask their children about the above symptoms—children and teenagers are more likely than adults to experience these seizures.

The risk of photosensitive epileptic seizures may be reduced by taking the following precautions:

- Sit farther from the television screen
- Use a smaller television screen
- Play in a well-lit room
- Do not play when you are drowsy or fatigued

If you or any of your relatives have a history of seizures or epilepsy, consult a doctor before playing.

### About Musculoskeletal Disorders

Use of game controllers, keyboards, mice, or other electronic input devices may be linked to serious injuries or disorders.

When playing video games, as with many activities, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. However, if you experience symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensation, or stiffness, **DO NOT IGNORE THESE WARNING SIGNS. PROMPTLY SEE A QUALIFIED HEALTH PROFESSIONAL**, even if symptoms occur when you are not playing a video game. Symptoms such as these can be associated with painful and sometimes permanently disabling injuries or disorders of the nerves, muscles, tendons, blood vessels, and other parts of the body. These musculoskeletal disorders (MSDs) include carpal tunnel syndrome, tendonitis, tenosynovitis, vibration syndromes, and other conditions.

While researchers are not yet able to answer many questions about MSDs, there is general agreement that many factors may be linked to their occurrence, including medical and physical conditions, stress and how one copes with it, overall health, and how a person positions and uses their body during work and other activities (including playing a video game). Some studies suggest that the amount of time a person performs an activity may also be a factor.

Some guidelines that may help you work and play more comfortably and possibly reduce your risk of experiencing an MSD can be found in the Healthy Gaming Guide (available at <http://www.xbox.com/support>). These guidelines address topics such as:

- Positioning yourself to use comfortable, not awkward postures.
- Keeping your hands, fingers, and other body parts relaxed.
- Taking breaks.
- Developing a healthy lifestyle.

If you have questions about how your own lifestyle, activities, or medical or physical condition may be related to MSDs, see a qualified health professional.

## SELECTING A LOCATION FOR THE XBOX CONSOLE

### Select a Safe Location

When selecting a location for the Xbox video game system, consider the following topics and the **Important Safety Information** on page 2.

### Prevent the Xbox Console from Falling

If the Xbox console falls and hits someone, especially a small child, it could cause serious injury. To reduce the risk of such injuries and damage to the Xbox console, place the Xbox console on a surface that:

- is flat and level.
- is stable and not likely to tip over.
- allows all four feet of the Xbox console to be in contact with the surface.
- is clean and free of dust or debris.
- is not likely to allow the Xbox console to slip or slide off.

### Take Precautions with Cables and Cords

Arrange all cables and cords so that people and pets are not likely to trip over or accidentally pull on them as they move around or walk through the area.

When the Xbox console is not in use, you may need to disconnect all cables and cords in the front and rear of the Xbox console to prevent children from pulling on them. Do not allow children to play with cables or cords.

Do not touch the metal parts of any cord coming out of the Xbox console when the Xbox console is plugged in to power.

### Prevent the Xbox Console from Overheating

Do not block any ventilation openings. Do not place the Xbox console on a bed, sofa, or other soft surface that may block ventilation openings.

Do not place the Xbox console in a confined space, such as a bookcase, rack, or stereo cabinet, unless the space is well ventilated.

Do not install the Xbox console near any heat sources, such as radiators, heat registers, stoves, or other devices (including amplifiers) that produce heat.


### Avoiding Damage to Your Television or Other AV Equipment

**Do not use with certain televisions.** Some televisions, especially front- or rear-projection types, can be damaged if any video games, including Xbox games, are played on them. Static images presented during the normal course of gameplay may "burn" into the screen, causing a permanent shadow of the static image to appear at all times, even when video games are not being played. Similar damage may occur from static images created when placing a video game on hold or pause. Consult your television owner's manual to determine if video games can be played safely on your set. If you are unable to find this information in the owner's manual, contact your television dealer or the manufacturer to determine if video games can be played safely on your set.

Before connecting or disconnecting any AV device (for example, television or VCR), make sure that the Xbox console is unplugged from the power outlet and that the power to the TV, VCR, or other AV device is turned off. This will reduce the risk of electrical shock or electrical damage to the equipment.

To avoid the risk of electrical shock or damage to AV equipment or to the Xbox console, do not touch AV cord terminals or the Xbox AV port with your fingers or allow metal parts to touch them.

## CONNECTING TO A TV



### Connecting Using the Xbox Standard AV Cable

If your TV has composite video input, use the standard AV cable included with the Xbox video game system.

#### To connect to a TV


1. Make sure that the Xbox console is unplugged from the power outlet.
2. Connect the Xbox AV connector to the AV port on the Xbox console.
3. Connect the color-coded connectors to the corresponding jacks on the TV: yellow to yellow (video), red to red (right audio), and white to white (left audio). Jacks may be on the front or back of the TV.

**Note:** For monaural TVs, which have only one audio jack, connect either the right or left audio connector to the audio jack.

4. Plug the Xbox console into the power outlet.
5. Select the appropriate video input on your TV. For more information, see **Input Selection below**.

You may not be able to connect to your TV using the standard AV cable. If you have antenna, S-video or component video input, or digital audio input, use the appropriate Xbox AV pack or adapter (sold separately). For more information, see <http://www.xbox.com> or **Xbox Peripherals** on page ii.

If your TV is connected to a VCR and the VCR has composite (integrated) video input, you can use the standard AV cable to connect to the VCR.



#### To connect to a VCR

1. Make sure that the Xbox console is unplugged from the power outlet.
2. Connect the Xbox AV connector to the AV port on the Xbox console.
3. Connect the color-coded connectors to the corresponding jack on the VCR: yellow to yellow (video), red to red (right audio), and white to white (left audio).
 

**Note:** For monaural VCRs, connect either the right or left audio connector to the audio jack.
4. Do not change the existing connection between the VCR and TV.
5. Plug the Xbox console into the power outlet.
6. Select VCR for the TV/VCR setting of the VCR.
7. Select the appropriate video input on your VCR. For more information, see **Input Selection below**.

#### Input Selection

Select the video input on the TV or VCR that displays the Xbox game. Typical ways to locate the input selection on your TV or VCR are:

- Pressing a button on the front of the TV or VCR, possibly behind a hidden panel.
- Pressing a button on the original remote control.
- Selecting low or high channel numbers.
- Using an on-screen menu option.

**Note:** Depending on the type/make of your TV or VCR, the following are common names for video input selection: Input Select, AUX, Video, Line, Line In, Input, Source, In, and EXT.

For more information, see your TV or VCR manual.

## CONNECTING XBOX CONTROLLERS

### Connecting and Disconnecting Xbox Controllers


To connect an Xbox controller, insert the Xbox controller connector into any controller port on the front of the Xbox console.

To disconnect, unplug the Xbox controller connector from the Xbox controller port. When disconnecting, pull on the controller connector, not the cable or inline release.

Do not touch Xbox controller cord terminals or the Xbox controller ports with your fingers or allow metal parts to touch them. Doing so may damage the Xbox controller or the Xbox console.

### Using the Xbox Controller in Games

For information about using the Xbox controller with a game, see your game manual.



## USING XBOX CONTROLLERS

### Inline Release


Each Xbox controller cord has an inline release. This is a safety feature designed to reduce the chance of the Xbox console falling when the cord is pulled. If the Xbox console falls and hits someone, especially a small child, it could cause serious injury. To reduce the risk of such injuries or of damage to the Xbox console, it is important to properly use the Xbox controllers and the inline release.

Use the Xbox controller connector, not the inline release, to routinely connect and disconnect the Xbox controller. If an inline release disconnects, simply reconnect it by aligning the grooved indentations on the two parts of the inline release and pressing the two parts completely together. Do not touch any metal parts of the inline release when the Xbox console is plugged into power. The Xbox controller will not work unless the inline release is properly connected.

**WARNING!** Never tape, glue, or otherwise prevent an inline release from pulling apart.


The inline release reduces, but does not eliminate, the risk of the Xbox console being pulled off its surface. To further reduce the risk:

- Do not allow anyone to pull on the Xbox controllers or controller cords in a way that causes the Xbox console to move.



- Do not allow Xbox controller cords to become crossed or tangled with one another.
- Read and follow the instructions in **Selecting a Location for the Xbox Console** on page 5.


## USING XBOX CONTROLLERS



### Using Xbox Controller Expansion Slots

The Xbox controller has two expansion slots that allow you to connect expansion devices to the Xbox controller. For example, you can add portable storage to the Xbox video game system by connecting an Xbox Memory Unit (shown) (sold separately). If you are playing on the Xbox *Live* service, you may want to add the Xbox Communicator (sold separately) for voice communication. For more information, see **Xbox Peripherals** on page ii.

## TURNING ON THE XBOX CONSOLE



Make sure that all connections to the TV, VCR, or other AV devices are complete. Plug the power cord into the Xbox console, and then fully insert the plug into the power outlet. See **General Electrical Precautions** on page 3 for more information.

Turn on the Xbox console by pressing the power button. The status indicator light will light up.

Turn off the Xbox console by pressing the power button. To eliminate all voltage inside the Xbox console, turn off the Xbox console, and then unplug the power cord from the power outlet.

## INITIAL SETUP

The first time you turn on your Xbox video game system, you must set the default language and the clock before playing a game or audio CD. Once these settings are specified, you don't have to set them again if you leave the Xbox console connected to power.

To move the selection focus on the screen, press the directional pad of the Xbox controller. To select, press A. To cancel, press B.



## AUDIO, VIDEO AND OTHER SETTINGS

In addition to the initial language and clock settings, you can specify other settings for the Xbox video game system. To choose settings for your system, turn on the Xbox video game system without a disc in the disc tray.


### To choose audio or video settings

1. Select **Settings**, and then select **Audio** or **Video**.
2. Select appropriate options for your system.


You can configure the Xbox console to automatically turn off if left unattended for six hours.

### To choose Auto Off

1. Select **Settings**, and then select **Auto Off**.
2. Select **Yes** to have the Xbox console turn off automatically, or **No** (the default).



## PLAYING GAMES AND MUSIC



### Playing Games

The Xbox video game system can play only game discs licensed by Microsoft for the Xbox video game system. Licensed games have this logo:



#### To start a game

1. Press the eject button to open the disc tray.
2. Place the Xbox game disc on the disc tray with the label facing up.
3. Press the eject button to close the disc tray. The game will play.

#### To switch to another game

1. Press the eject button to open the disc tray.
2. Remove the game disc.
3. Place a new Xbox game disc on the disc tray.
4. Press the eject button to close the disc tray. The new game will play.

#### To end a game

1. Press the eject button and the disc tray will open.
2. Remove the Xbox game disc.
3. Press the eject button again to close the disc tray.

### Playing Music

The Xbox video game system can play audio CDs that have this logo:



#### To play audio CDs

1. Press the eject button to open the disc tray.
2. Place the audio CD on the disc tray with the label facing up.
3. Press the eject button to close the disc tray. The audio CD will play.

### Playing DVD Movie Discs

To play DVD movies on the Xbox video game system, you need the Xbox DVD Movie Playback Kit (sold separately). For more information about playing DVD movies, see the Instruction Manual for the Xbox DVD Movie Playback Kit.

#### Avoiding Damage to Discs or to the Disc Drive

- Do not leave a disc in the Xbox console for extended periods when not in use.
- Do not move the Xbox console while the power is on and a disc is inserted.
- Do not apply labels, stickers, or other foreign objects to discs.

## SOUNDTRACKS


You can copy tracks from audio CDs using the Xbox video game system. Then you can arrange these tracks into soundtracks and play them from the Xbox video game system without inserting the original CD audio disc. You can play your soundtracks while playing Xbox games if this feature is supported by the game. To find out whether a game title supports soundtrack play, and how to play the soundtrack during that particular game, see the game instruction manual.

### To copy tracks

1. Play an audio CD.
2. Select **Back** from the music player.
3. Select **Copy** to display tracks.
4. Select the tracks you want to copy. You can select one track, multiple tracks, or all tracks.
5. Select **Copy** to begin copying the tracks.
6. Select an existing soundtrack, or create a new soundtrack to store the copied tracks. If you create a new soundtrack, enter a name using the virtual keyboard.

### To play soundtracks

1. Turn on the Xbox console with no disc in the disc tray.
2. Select **Music** on the Xbox Dashboard.



3. Under **Music** you will see **Audio CD**. Every soundtrack you have saved is listed here under the names you have created.
4. Choose the soundtrack you want to play.
5. Select **Play** to begin playing.

## PARENTAL CONTROL


You can limit the type of content played on the Xbox video game system based on the ESRB rating level. By default, the Xbox video game system is set to play all content. You can select separate parental control levels for games and DVD movies. To play DVD movies on the Xbox video game system, you need the Xbox DVD Movie Playback Kit (sold separately).

### To change the level of content that can be played


1. Turn on the Xbox console with no disc in the disc tray.
2. Select **Settings**, then select **Parental Control**, and then select **Games**.
3. Select the new level: **All**, **M** (Mature), **T** (Teen), **E** (Everyone), **K-A** (Kids to Adults), **EC** (Early Childhood), or **None**.

The Xbox video game system will play games and DVD movies that are rated at or below the selected level. For example, if the selected level is **T**, games rated **T**, **E**, **K-A**, and **EC** can play. If you choose any level other than **All**, you must select a pass code.

If you lose or forget your pass code, call the Xbox Customer Support number on page ii.



## MANAGING MEMORY




The Xbox video game system includes an internal hard disk for saving game information and soundtracks. For information about saving games, see your Xbox game manual. For information about saving soundtracks, see **Soundtracks** on page 11.

To manage or free space on the Xbox hard disk, you can remove all stored information and saved games for a given Xbox game, or copy or delete specific saved games.

### To remove all information about a game

1. Turn on the Xbox console with no disc in the disc tray.
2. Select **Memory**, and then select **Xbox Hard Disk**.
3. Select a game.




4. Select **Remove Game** to delete the selected game, including all its saved games, from the Xbox hard disk. Select **Yes** when prompted, "Are you sure you want to permanently remove this title?"

### To copy or delete a saved game

1. Turn on the Xbox console with no disc in the disc tray.
2. Select **Memory**, and then select **Xbox Hard Disk**.
3. Select an individual saved game name in the collection of saved games.
4. Select **Copy** to move that saved game to an **Xbox Memory Unit** (sold separately) or **Delete** to remove the selected game from the Xbox hard disk. When deleting, select **Yes** when prompted, "Are you sure you want to permanently remove this saved game?"

## MULTIPLAYER GAMES



Connect up to four Xbox controllers to the Xbox console for games that allow multiple players. Not all Xbox games will allow multiple players. To determine if the game allows multiple players, see your game manual.

Some games can be played using the Xbox System Link Cable (sold separately), which connects two Xbox consoles for head-to-head gameplay. For more information, see the instruction manual for the Xbox System Link Cable.

**XBOX LIVE™**
**Xbox Live System Requirements**

- Xbox video game system
- Game with Xbox Live logo (sold separately)
- High-speed Internet service (cable or DSL)
- Connection to Xbox console via Ethernet cable (not included)
- Subscription to Xbox Live Service (sold separately)

Performance may vary based on Internet service speed, network activity, or capacity. Depending on your Internet service connection or network configuration, additional hardware may be required. While most cable or DSL high speed Internet services will work with Xbox Live, some may not—check with your service provider.

Xbox Live only available in the U.S. and Canada. Use is subject to the Xbox Live Terms of Use. Major credit card required. Not intended for children under the age of 13.

**Important!** Xbox Live is a subscription service. You will need a subscription code to set up an Xbox Live account and play online. To find out how to get a subscription code, visit your local retailer or see [www.xbox.com/live](http://www.xbox.com/live).

**CONNECTING HARDWARE**


To connect your Xbox console directly to a high-speed Internet service, see A.

To share your high-speed Internet connection with a PC, see B.

For more details and other home networking options, see [www.xbox.com/live](http://www.xbox.com/live).

**A. Direct Connection**


You can connect the Ethernet cable provided with your Cable or DSL modem directly to the Ethernet port on the back of the Xbox console. Some configuration of the Xbox Network Settings may be required (see **Configuring the Xbox Dashboard** on page 14).


**B. Shared Connection**

A Cable/DSL router allows both the Xbox console and PC to connect to your Cable modem, DSL modem, or other high-speed Internet device at the same time.

- Connect the Ethernet port on the Cable/DSL modem to the WAN or Uplink port on the Cable/DSL router.
- Connect the PC to one of the available Ethernet LAN ports on the Cable/DSL router.
- Connect the Ethernet port on the back of the Xbox console to one of the available Ethernet LAN ports on the Cable/DSL router.

**Note:** Some Cable modems, DSL modems, and high-speed Internet devices may require a network hub instead of a Cable/DSL router. You may still use diagram B.





## UPDATING THE XBOX DASHBOARD

Before you can sign up for the Xbox *Live* service and begin playing games online, the Xbox Dashboard must be updated. To update the Xbox Dashboard:

1. Insert an Xbox *Live* Starter Kit disc or game disc into the disc tray. Check the game packaging to see if the game supports Xbox *Live* play.
2. From within the game, select the option for Xbox *Live*.

### Configuring the Xbox Dashboard (if necessary)

The Xbox console will attempt to automatically configure itself to use your broadband connection when you select the option for Xbox *Live* from within the game.

Many ISPs require specific settings before allowing access to the Internet. These settings may include a host name, MAC address, or an ISP user name and password (for PPPoE authentication). If you are unsure about whether you need this information, check with your broadband service provider.

For more detailed information about Network Settings in the Xbox Dashboard, and other support issues, see [www.xbox.com/live](http://www.xbox.com/live).

## XBOX LIVE SIGN UP

**Note:** You will not be able to establish an account until the Xbox Dashboard has been updated for Xbox *Live*. See **Updating the Xbox Dashboard** above.

### Signing Up for a New Account

To create a new account, select the option for Xbox *Live* from the Xbox Dashboard. Follow the instructions on screen, and enter your subscription code (see **Xbox Live System Requirements** on page 13) when prompted.

### IF YOU NEED MORE HELP

Please see [www.xbox.com/live](http://www.xbox.com/live) or call the Xbox Customer Support number:

**United States and Canada:**  
1-800-4MY-XBOX (1-800-469-9269)

**TTY users (requires special equipment for hard of hearing):**

**United States and Canada:**  
1-866-740-9269 or 1-425-635-7102

## CLEANING THE XBOX VIDEO GAME SYSTEM

### Cleaning the Xbox Console

It is important to keep the rubber feet on the bottom of the Xbox console clean and free of dust and debris to reduce the risk of the Xbox console falling and possibly hitting someone.

- If the rubber feet ever become dirty or dusty, wipe them off with a dry cloth.
- Keep the surface on which the Xbox console rests clean by wiping with a dry cloth.

### If you clean the Xbox console:

- Unplug the Xbox console from the power outlet.
- Clean the outside of the Xbox console only. Make sure that no objects are inserted into ventilation openings.

- Use a dry cloth—do not use abrasive pads, detergents, scouring powders, solvents (for example, alcohol, gasoline, paint thinner, or benzene), or other liquid or aerosol cleaners.

### To clean Xbox game discs or audio CDs

- Hold discs by the edges; do not touch disc surface with fingers.
- Clean discs using a soft cloth, lightly wiping from the center outwards.
- Do not use solvents such as benzene, which can damage the disc.

## TROUBLESHOOTING

**WARNING**

To reduce the risk of serious injury or death from electric shock or fire, do not attempt to service or repair the Xbox console. Do not attempt to take apart the Xbox console or modify it in any way. Refer all servicing to qualified service personnel.

Please follow these steps to troubleshoot difficulties with the Xbox video game system:

**No Power**

Connect the power cord (see **Turning On the Xbox Console** on page 8).

**Status Indicator Light Flashes Continually**

The status indicator light should be green while the Xbox video game system is on, or flash green when you press the eject button. If the status indicator light flashes continually during operation, the Xbox video game system has an internal problem:

- Continual orange flashing: The Xbox console is too hot and will not play games until cooled. Place the Xbox console in a well-ventilated area away from other heat sources. Once the console cools, the flashing will stop and the Xbox video game system can be played. For more information, see **Selecting a Location for the Xbox Console** on page 5.
- Continual green and orange flashing: The AV cable is not connected properly. Connect according to the instructions in **Connecting to a TV** on page 6.
- All other patterns: Internal problem requires service. Contact Xbox Customer Support according to the instructions in **If You Need Help...** on page 16.

**Disc Tray Does Not Open**

Connect the power cord (see **Turning on the Xbox Console** on page 8).

Turn on the Xbox console by pressing the power button (see **Turning On the Xbox Console** on page 8).

**Game Does Not Start**

Play only licensed Xbox game discs (see **Playing Games and Music** on page 10).

Insert the disc with the label up and close the disc tray (see **Playing Games and Music** on page 10).

Clean the disc (see **Cleaning the Xbox Video Game System** on page 14).

**No Picture**

Connect the appropriate AV cable (see **Connecting to a TV** on page 6).

Turn on the TV.

Select the video input on the TV or VCR that displays the Xbox game. Typical ways to locate the input selection on your TV or VCR are:

- Pressing a button on the front of the TV or VCR, possibly behind a hidden panel.
- Pressing a button on the original remote control.
- Selecting low or high channel numbers.
- Using an on-screen menu option.

*Note* Depending on the type/make of your TV or VCR, the following are common names for video input selection: Input Select, AUX, Video, Line, Line In, Input, Source, In, and EXT.

For more information, see your TV or VCR manual.

Play only supported types of discs (Xbox games, audio CDs; see **Playing Games and Music** on page 10).

**Poor-Quality Picture**

Clean the disc (see **Cleaning the Xbox Video Game System** on page 14).

**No Sound**

Properly connect the AV cable (see **Connecting to a TV** on page 6).

Check the volume on the TV and turn off TV mute (see your TV manual).

Select the correct audio output (see **Connecting to a TV** on page 6).

Play only supported types of discs (Xbox games, audio CDs; see **Playing Games and Music** on page 10).

**Poor-Quality Sound**

Clean the disc (see **Cleaning the Xbox Video Game System** on page 14).

Play Dolby® Digital audio only to speakers that support Dolby Digital.

Select the audio output that is supported by your system or TV (Stereo or Dolby® Surround for stereo speakers, Mono for monaural speakers). (See **Audio, Video, and Other Settings** on page 9).

If sound is coming from only one speaker, check that all audio cables are connected correctly.



## TROUBLESHOOTING

### Xbox Controller or Peripheral Does Not Work

Connect the Xbox controller to any controller port (see **Connecting Xbox Controllers** on page 7).

Make sure the controller connectors, including the inline release, are connected securely (see **Using Xbox Controllers** on page 7).

Use only Xbox-compatible peripherals that have this logo:



For a list of Microsoft's Xbox peripheral products, see **Xbox Peripherals** on page ii.

Make sure the Xbox game supports any optional peripherals connected to the Xbox video game system. If a peripheral is not supported by the specific game, the game may not play.

### Cannot Save Game

The Xbox hard disk or memory unit must have enough free blocks to save the game. For information on how to free space, see **Managing Memory** on page 12.

### If You Need Help...

Should problems persist, do not attempt to take apart, service, or modify the Xbox console in any way. Doing so could present the risk of serious injury or death from electric shock or fire, and it will void your warranty. Please see [www.xbox.com](http://www.xbox.com) or call the Xbox Customer Support number:

**United States and Canada:**  
1-800-4MY-XBOX (1-800-469-9269)

**Mexico:** 001 866 745 83 12

**TTY users (requires special equipment for hard of hearing):**

**United States and Canada:**  
1-866-740-9269 or 1-425-635-7102

**Mexico:** 001 866 251 26 21

Do not take your Xbox video game system or peripheral to your retailer for repair or service, unless instructed to do so by an Xbox Customer Support representative.

## SPECIFICATIONS

### General

Power requirements: 120 V AC, 60 Hz

Power consumption: 100 W

Dimensions (approximate): 320 x 100 x 260 mm;  
12.5 x 4 x 10.5 inches (w/h/d)

Mass (approximate): 4 kg (8 lb 13 oz)

Operating temperature: 5 °C to 35 °C (41 °F to 95 °F)

Laser diode properties: Material: GaAlAs,  
Wavelength:  $\lambda = 650 \text{ nm}$

### Inputs/Outputs

Controller ports (4)

Ethernet port (1)

AV port (1)

AC IN power port (1)

### Supplied Peripherals

See **The Xbox Video Game System** on page ii.

### Optional Peripherals

See **Xbox Peripherals** on page ii.

### Product Disposal Information

Dispose of this product in accordance with local and national disposal regulations.

Design and specifications are subject to change without notice.

**WARRANTY**

PLEASE READ THIS LIMITED WARRANTY CAREFULLY TO UNDERSTAND YOUR RIGHTS AND OBLIGATIONS!

**LIMITED WARRANTY**

The term "Xbox Product" means the Microsoft Xbox Video Game System console including (when considered as a whole) the Microsoft software stored on the hard disk and embedded in microprocessors within the Xbox console, and Xbox-compatible hardware manufactured by or for Microsoft, whether included with the Xbox Video Game System or purchased separately.

**A. WARRANTIES**

**1 90-Day Express Warranty.** Subject to the terms and conditions of this Limited Warranty, Microsoft warrants to you only (the original purchaser), that under normal use and service the Xbox Product will substantially conform with the accompanying printed user instruction materials for a period of 90 days starting as of the date of your sales receipt (the "Warranty Period").

**2 Implied Warranty.** You may also have an implied warranty and/or condition under the laws of some jurisdictions, which is hereby limited to the duration of the Warranty Period. Some jurisdictions do not allow limitations on how long an implied warranty or condition lasts, so the foregoing limitation may not apply to you.

As to any defects discovered after the Warranty Period, there is no warranty or condition of any kind.

**B. OBTAINING WARRANTY SERVICE.** To receive instructions for obtaining repair or replacement warranty services you must call:

**Within the U.S., U.S. Territories and Canada:**  
1-800-4MYXBOX (1-800-469-9269)

**TTY users (requires special equipment for hard of hearing):**  
**Within the U.S., U.S. Territories and Canada:**  
1-866-740-9269 or 1-425-635-7102

**You must also:**

1. Submit proof of purchase in the form of a bona fide, dated bill of sale, receipt, or invoice (or a copy) evidencing that your request for service is made within the Warranty Period.

2. Follow Microsoft's shipping and other instructions if it determines that all or part of your Xbox Product requires return for repair or replacement. To obtain the warranty service, you must take or deliver the Xbox Product in either its original packaging or packaging that provides an equal degree of protection to the location specified by Microsoft. Except as otherwise required by legislation in your jurisdiction, costs associated with transport (including packaging) for warranty service shall be at your expense.

3. Delete or remove any files or data you consider private or confidential prior to sending the Xbox Product to Microsoft.

**Failure to follow the above instructions may result in delays, cause you to incur additional charges, or may void your warranty.**

**C. EXCLUSIVE REMEDY.** During the Warranty Period and subject to applicable law, Microsoft will, at its option and as your exclusive remedy for breach of this Limited Warranty or any implied warranties:

1 Repair or replace a defective Xbox Product, or

2 Following return of your Xbox Product, make payment to you for the allowable damages that you incur in reasonable reliance but only up to the amount of the purchase price that you paid for your Xbox Product. This refund may include a deduction for depreciation based on your actual use.

3 Any replacement parts or Xbox Product will be new or refurbished or serviceably used, comparable in function and performance to the original part or Xbox Product and warranted for the remainder of the original Warranty Period or 30 days from the date of shipment of the Xbox Product back to you, whichever is longer.

**4 Microsoft may, at its sole option, elect to replace the hard disk contained in your Xbox Product even if this causes a loss of data. YOU AGREE THAT MICROSOFT IS NOT LIABLE TO YOU FOR ANY LOSS OF YOUR DATA.**

5 After the Warranty Period has expired, Microsoft may charge you a fee for its efforts to diagnose and service any Xbox Product-related problems.

6 Microsoft will use commercially reasonable efforts to diagnose and attempt to correct, or suggest solutions for, Xbox Product defects that are covered by this Limited Warranty. **MICROSOFT DOES NOT PROVIDE ANY WARRANTIES REGARDING ITS WARRANTY SERVICES AND, EXCEPT FOR THE PRECEDING SENTENCE, DISCLAIMS ALL DUTIES (IF ANY) OF WORKMANLIKE EFFORT OR OF LACK OF NEGLIGENCE.**

**D. NO OTHER WARRANTIES.** The express warranty stated in Section A above is the only express warranty made to you and is provided in lieu of all other express or implied warranties and conditions (if any) including any created by any other documentation or packaging. No other warranties or conditions are made with respect to the Xbox Product or the warranty services by any person, including but not limited to Microsoft and its suppliers. **No information (oral or written) or suggestions given by Microsoft, its agents or suppliers or its or their employees, shall create a warranty or condition or expand the scope of this Limited Warranty.** Also, there is no warranty or condition of title, quiet enjoyment, or noninfringement in the Xbox Product. You may have greater rights existing under legislation in your jurisdiction. Where any term of this Limited Warranty is prohibited by such laws, it shall be null and void, but the remainder of the Limited Warranty shall remain in full force and effect.



## WARRANTY

**E. EXCLUSIONS FROM LIMITED WARRANTY.** This Limited Warranty shall not apply and Microsoft has no liability under this Limited Warranty if the Xbox Product:

- 1 is used with products not sold or licensed by Microsoft (including, but not limited to, non-licensed games and game enhancement devices, adaptors and power supply sources) or which are otherwise not compatible;
- 2 is used for commercial purposes (including rental or lease);
- 3 is modified or tampered with;
- 4 is damaged by Acts of God, power surge, misuse, abuse, negligence, accident, wear and tear, mishandling, misapplication, or other causes unrelated to defective materials or workmanship;
- 5 serial number is defaced, altered or removed;
- 6 is damaged by programs, data, viruses, or files, or during shipments;
- 7 is not used in accordance with the accompanying documentation and use instructions; or
- 8 is repaired, modified or altered by other than Microsoft authorized repair centers.

This Limited Warranty does not cover your data, any separate software or Xbox games whether or not packaged or included with the Xbox Product, or any Xbox accessories or peripheral devices that are not manufactured by or for Microsoft.

**F. EXCLUSION OF CONSEQUENTIAL, INCIDENTAL AND CERTAIN OTHER DAMAGES and LIMITATION OF LIABILITY**

TO THE FULL EXTENT ALLOWED BY LAW, MICROSOFT IS NOT LIABLE FOR ANY:

- (i) CONSEQUENTIAL OR INCIDENTAL DAMAGES;
- (ii) DAMAGES OR LOSS OF ANY NATURE WHATSOEVER RELATING TO LOST PROFITS, LOSS OF DATA OR PRIVACY OR CONFIDENTIALITY, ANY INABILITY TO USE ALL OR PART OF THE XBOX PRODUCT, PERSONAL INJURY, OR ANY FAILURE TO MEET ANY DUTY (INCLUDING BUT NOT LIMITED TO ANY LACK OF NEGLIGENCE OR OF WORKMANLIKE EFFORT); OR
- (iii) INDIRECT, SPECIAL, OR PUNITIVE DAMAGES; ARISING OUT OF RELATING IN ANY WAY TO THE XBOX PRODUCT.

THE FOREGOING APPLIES EVEN IF MICROSOFT OR ANY SUPPLIER OR AGENT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSSES OR DAMAGES; EVEN IN THE EVENT OF FAULT, TORT (INCLUDING NEGLIGENCE), STRICT OR PRODUCT LIABILITY, MISREPRESENTATION OR OTHER REASON; AND EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

**G. ADDITIONAL CONDITIONS**

The software included in the Xbox Product is licensed to you, not sold. You are licensed to use such software only in your Xbox Product and you may not reverse engineer it, except as expressly permitted by applicable law notwithstanding this limitation.

Your Xbox Product and its internal components are new pursuant to industry standards, unless otherwise indicated on the Xbox Product retail packaging as "Refurbished".

You agree to comply with all applicable export laws and regulations if you export the Product outside of the United States or Canada.

This Limited Warranty applies to the original purchaser only and may not be assigned or transferred. However, some jurisdictions extend the protection of implied warranties to subsequent consumers and therefore this limitation may not apply to you.

**H. GOVERNING LAW.** This Limited Warranty is valid only in the United States of America and Canada. If you acquired the Product in the United States, the laws of the State of Washington, U.S.A., will apply to this Limited Warranty.

If you acquired the Product in Canada, except where expressly prohibited by local law, the laws in force in the Province of Ontario, Canada will apply.

**I. QUESTIONS?** Please call 1-800-4MYXBOX (1-800-469-9269) within the U.S., U.S. Territories and Canada.

This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from jurisdiction to jurisdiction.

## ESRB RATINGS GUIDE

As a parent today, do you feel like you don't know what's in those computer and video games your kids like to play? Do you need more information about what Internet Web sites and interactive games are appropriate for your child?

The control is in your hands.

### Check the Rating

Almost every computer and video game has a rating symbol and a content descriptor right on the box. The rating symbol tells you what age group the game is appropriate for. The content descriptor outlines the content of the game.

### Why Use a Rating System?

The rating system is an unbiased, standardized way to help you determine whether a game is appropriate for your child. Ratings are determined by the Entertainment Software Rating Board (ESRB), an independent board developed with the support of the computer and video game industry.

### About the Content Descriptors

In addition to the rating, consumers should check for important content information (also called "descriptors") in the black-and-white box on the back of the package. These content descriptors give more details about the product in terms of violence, sexual themes, language, and other areas that may be of interest to some consumers. If there is no content descriptor on the back of the package, the Rating Board believes that the product does not include content that must be highlighted.

### Contact Us

The ESRB has established a toll-free line (United States and Canada only) at 1-800-771-ESRB (3772) and Web site at <http://www.esrb.org> so that parents and consumers can access up-to-date rating information. These consumer aids are also available in French and Spanish.

If you have any questions or require any additional information, please contact the ESRB at:

ESRB  
845 Third Avenue  
New York, N.Y. 10022  
Phone: 212-759-0700  
Fax: 212-759-2223  
E-mail: [info@esrb.org](mailto:info@esrb.org)



### EARLY CHILDHOOD

Content may be suitable for persons ages 3 and older. Contains no material that parents would find inappropriate.



### EVERYONE

Content may be suitable for persons ages 6 and older. May contain minimal violence and some comic mischief or crude language.



### TEEN

Content may be suitable for persons ages 13 and older. May contain violent content, mild or strong language, and/or suggestive themes.



### MATURE

Content may be suitable for persons ages 17 and older. May contain mature sexual themes or more intense violence or language.



### RATING PENDING

Product has been submitted to the ESRB and is awaiting final rating.



### ADULTS ONLY

Content suitable only for adults. May include graphic depictions of sex and/or violence. Not intended for persons under the age of 18.

Information in this document, including URL and other Internet Web site references, is subject to change without notice. Unless otherwise noted, the example companies, organizations, products, domain names, e-mail addresses, logos, people, places and events depicted herein are fictitious, and no association with any real company, organization, product, domain name, e-mail address, logo, person, place or event is intended or should be inferred. Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of Microsoft Corporation.

Microsoft may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from Microsoft, the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property.

© 2001-2003 Microsoft Corporation. All rights reserved.

Microsoft, Xbox, Xbox *Live*, and the Xbox logos are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories. Confidential unpublished works. Copyright 1999-2001 Dolby Laboratories. All rights reserved.

The names of actual companies and products mentioned herein may be the trademarks of their respective owners.

Les informations contenues dans le présent document, y compris les URL et autres références à des sites Web, peuvent faire l'objet de modifications sans préavis. Sauf indication contraire, les entreprises, organismes, produits, noms de domaine, adresses électroniques, logos, personnes, lieux et événements figurant dans ce manuel sont fictifs et sans quelconque rapport, intentionnel ou implicite, avec une entreprise, un organisme, un produit, un nom de domaine, une adresse électronique, un logo, une personne, un lieu ou un événement réels. L'utilisateur est tenu d'observer la réglementation relative aux droits d'auteur, applicable dans son pays. Sans limitation des droits d'auteur, aucune partie de ce document ne peut être reproduite, stockée ni introduite dans un système de restitution, ou transmise à quelque fin, par quelque moyen que ce soit (électronique, mécanique, photocopie, enregistrement ou autre) ou dans un but quelconque, sans la permission expresse et écrite de Microsoft Corporation.

Microsoft peut détenir des brevets, avoir déposé des demandes d'enregistrement de brevets ou être titulaire de marques, droits d'auteur ou autres droits de propriété intellectuelle portant sur la totalité ou une partie des éléments qui font l'objet du présent document. Sauf stipulation expresse contraire d'un contrat de licence écrit de Microsoft, la fourniture de ce document n'a pas pour effet de vous concéder une licence sur ces brevets, marques, droits d'auteur ou autres droits de propriété intellectuelle.

© 2001-2003 Microsoft Corporation. Tous droits réservés.

Microsoft, Xbox, Xbox *Live*, et les logos Xbox sont des marques de commerce ou des marques déposées de Microsoft Corporation aux États-Unis et (ou) dans d'autres pays.

Ce produit intègre une technologie de protection du copyright qui est protégée par des revendications de méthode inhérentes à certains brevets américains et autres droits de propriété intellectuelle détenus par Macrovision Corporation et d'autres détenteurs de droits. L'utilisation de cette technologie de protection du copyright doit être approuvée par Macrovision Corporation et est réservée à un usage privé et limité, sauf mention contraire par Macrovision Corporation. L'ingénierie inverse ou le désassemblage est interdit.

Fabriqué sous licence de Dolby Laboratories. Le terme « Dolby » et le symbole double-D sont des marques déposées de Dolby Laboratories. Oeuvres inédites confidentielles. Droits d'auteur, 1999-2001 Dolby Laboratories. Tous droits réservés.

Les noms de sociétés et de produits réels mentionnés dans ce manuel peuvent être des marques de commerce de leurs propriétaires respectifs.

La información contenida en este documento, como direcciones URL y otras referencias a sitios Web de Internet, está sujeta a cambios sin previo aviso. A no ser que se indique lo contrario, los nombres de compañías, organizaciones, productos, dominios, direcciones de correo electrónico, logotipos, personas, sitios y eventos de ejemplo mencionados son ficticios, y no debe deducirse ninguna asociación entre los mismos y los nombres de compañías, organizaciones, productos, dominios, direcciones de correo electrónico, logotipos, personas, lugares o eventos reales. El cumplimiento de todas las leyes de derechos de autor aplicables es responsabilidad del usuario. Sin limitar los derechos especificados en los derechos de autor, queda prohibida la reproducción, almacenamiento o ingreso en algún tipo de sistema de recuperación, o transmisión de cualquier parte de este documento de ninguna forma ni por ningún medio (electrónico, mecánico, fotocopiado, grabado, etc.), ni con ninguna finalidad, sin el consentimiento explícito por escrito de Microsoft Corporation.

Microsoft puede tener patentes, aplicaciones de patentes, marcas comerciales, derechos de autor u otros derechos de propiedad intelectual aplicables a los asuntos mencionados en este documento. Exceptuando lo explícitamente provisto en cualquier acuerdo de licencia por escrito de Microsoft, la entrega de este documento no le otorga ninguna licencia sobre dichas patentes, marcas comerciales, derechos de autor u otros derechos de propiedad intelectual.

© 2001-2003 Microsoft Corporation. Reservados todos los derechos.

Microsoft, Xbox, Xbox *Live*, y el logotipo de Xbox son marcas registradas o marcas comerciales de Microsoft Corporation en Estados Unidos y en otros países.

Este producto incorpora tecnología de protección de copyright mediante determinadas patentes de EE.UU. y otros derechos de propiedad intelectual propiedad de Macrovision Corporation y otros titulares. El uso de esta tecnología protegida por copyright debe ser autorizado por Macrovision Corporation y es únicamente para uso doméstico y para otras formas de vista limitadas, a menos que Macrovision Corporation autorice un uso distinto. Se prohíbe el desmontaje del aparato y la ingeniería inversa.

Fabricado bajo licencia de Dolby Laboratories. "Dolby" y el símbolo double-D son marcas comerciales de Dolby Laboratories. Trabajos confidenciales no publicados. Copyright 1999-2001 Dolby Laboratories. Reservados todos los derechos.

Los nombres de los productos y compañías reales mencionados en el presente documento son marcas comerciales de sus respectivos propietarios.

**Do not take your Xbox video game system or peripheral to your retailer for repair or service, unless instructed to do so by an Xbox Customer Support representative.**

**Ne confiez pas la réparation ni l'entretien de votre console de jeu vidéo Xbox ou des périphériques associés à votre revendeur, sauf instructions spécifiques de la part d'un représentant de l'assistance technique Xbox.**

**No lleve el Sistema de videojuegos Xbox ni un periférico a su distribuidor para que lo repare salvo que el servicio de atención al cliente Xbox así se lo indique.**

1002 Part Number X08-81789-02

**Microsoft**

